

---

## Read First

These suggestions represent generally accepted procedures for successful installation of Colbond Building Products. These instructions may be followed, modified, or rejected by the owner, engineer, contractor or their representative since they, not Colbond Inc., are responsible for planning and executing procedures appropriate to a specific application.

---

## Installation Bulletin

---

### Preparation

- Before beginning installation, inspect and approve quality of subsurface waterproofing and insulation to ensure that it is acceptable for subsurface drain installation and that the plaza has adequate slope to drain the area properly.
- Check compatibility of adhesive to waterproofing membrane.

---

### Installation

- Clean area of any loose debris.
- Start at plaza edge and install the Enkadrain with the fabric flap facing the edge of the wall.
- Cut Enkadrain to length so that the material fits tightly against all areas of the deck.
- Apply a bead of construction adhesive 0.125" to 0.25" in a zigzag pattern along the edge of the strip of Enkadrain without the fabric overlap. Install the next strip of Enkadrain — overlapping and bonding the fabric flap onto the previous strip.
- Repeat procedure until entire plaza deck floor is covered with geocomposite drain.
- Remove excess material from last strip without eliminating the fabric overlap.
- Proceed with soil, sand or aggregate fill of deck.

---

## Related Documents

### Enkadrain Brochure

#### Data Sheets

- Enkadrain 3611R
- Enkadrain 3615R
- Enkadrain 3811R
- Enkadrain 9120
- Enkadrain 9611 & 9615

#### Guide Specifications

- Enkadrain Specifications

*\*For additional technical assistance please contact: Colbond Inc., P.O. Box 1057, Enka, North Carolina 28728; TOLL FREE: 800-365-7391; PHONE: 828-665-5050; FAX: 828-665-5009; EMAIL: [enka-engineered@colbond.com](mailto:enka-engineered@colbond.com) or INTERNET: [www.colbond-usa.com](http://www.colbond-usa.com).*